



Pos	Part Number	Description	Additional Text	Quantity
1	7650910104430	FRONT WHEEL CPL. 1,85X21" 1		1.00
2	7530901004491	FRONT HUB CPL.		1.00
3	54809011000	BEA.SPACERTUBE 35X2 L=79,4 03		1.00
4	0625069068	Grooved ball bearing 6906		2.00
5	78009015000	FRONT WHEEL REP. KIT		1.00
6	0760354771	Radial shaft seal 35X47X7 TC		2.00
7	78009012000	SPACER BUSHING F. FR. WHEEL 08		2.00
8	55003135000	PLUG FOR RIM		1.00
9	7650917000030	Front rim 1.85X21" DID 16		1.00
10	75309073226	SPOKE M4,5X226-18" INOX		36.00

11	81210072100	SPOKE NIPPLE QUADRAX M4,5		36.00
12	58409073100	RIM BAND FRONT 2MM 2003		1.00
13	76509260000	FRONT BRAKE DISC D=300MM		1.00
14	60142020000	SENSOR WHEEL FRONT 06		1.00
15	014580060166S	SHCS ISO 14580 M6x16 SL		7.00
16	77309081000	WHEEL SPIN.FR. D=26 M24x1,5 07		1.00
17	54809081070	AUXILIARY SCREW FRONT 06		1.00
18	54809082000	SPINDLE SCREW M24X1,5 WS=27 03		1.00
19	54809081050	PLUG BUSHING WS=27 03		1.00
20	27042025000	ABS SENSOR		1.00
21	27042024100	SENSOR BRACKET		1.00
22	0018050103	INT. TORX OVAL HEAD M 5X10 8.8		2.00
23	0985060003	Self lock. nut DIN985-M6-A2		1.00