



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|--------------------------------|--------------------------|----------|
| 1 | 56012001000 | ASSY SUPPORT (WITHOUT HOLDER) | | 1.00 |
| 2 | 80029002100 | ENGINE HOLDER HUSABERG 04 | | 1.00 |
| 3 | 80029003000 | CLUTCH HOLDER 04 | | 1.00 |
| 4 | 80029004000 | GEAR SEGMENT CPL. 04 | | 1.00 |
| 5 | 80029005000 | MOUNT.SLEEVE F. LEFT SSR C.S. | | 1.00 |
| 5 | 80029105000 | MOUNT.SLEEVE F. RIGHT SSR C.S. | | 1.00 |
| 5 | 80029205000 | MOUNT.SLEEVE F. SSR KICKST.-S. | | 1.00 |
| 6 | 59029005010 | MOUNTING SLEEVE SEAL RING | FOR WATER PUMP-SEAL RING | 1.00 |
| 9 | 58012009000 | FLYWHEEL EXTRACTOR | 660 SMS | 1.00 |
| 10 | 58030080000 | LOCATING SCREW M8 L=23 | 450/525 MXC, EXC | 1.00 |
| 11 | 51012011000 | SPECIAL CIRCLIP PLIER | | 1.00 |

| | | | |
|----|-------------|--------------------------------|------|
| 15 | 60029015000 | PISTON RING COMPRESSOR CPL. 03 | 1.00 |
| 17 | 15112017000 | BUSHING EXTRACTOR | 1.00 |
| 18 | 15112018000 | INTERN.BEAR.PULLER 12-16 MM | 1.00 |
| 19 | 59029019000 | VALVE SPRING LEVER | 1.00 |
| 20 | 80029020000 | HOUSING SEPARATING TOOL 04 | 1.00 |
| 26 | 59029026006 | LIMIT PLUG GAUGE F.VALVE GUIDE | 1.00 |
| 30 | 80029030000 | RIVETTING TOOL TIMINIG CHAIN | 1.00 |
| 31 | 80029031000 | PROTECTION COVER F. CRANKSHAFT | 1.00 |
| 33 | 59029033000 | EXTRACTOR FOR TIMING GEAR | 1.00 |
| 35 | 80029035000 | PRESS OUT TOOL CONROD BEARING | 1.00 |
| 36 | 80029036000 | PRESS IN TOOL CONROD BEARING | 1.00 |
| 37 | 58429037037 | MOUNTING TOOL INNER RING NJ206 | 1.00 |
| 41 | 59029041000 | FEELER GAUGE SET10,12,15,20,25 | 1.00 |
| 50 | 50329050000 | VENT INJEKTION HYDR. CLUTCH | 1.00 |
| 52 | 80029052000 | SAFETY-TORX TX20 | 1.00 |
| 58 | 6899785 | LOCTITE 243 BLUE 5 ML | 1.00 |
| 59 | 80029059000 | LOCTITE 2701 GREEN 5ML | 1.00 |
| 60 | 309098 | SILICON GASKET THREE-BOND | 1.00 |
| 72 | 59029072000 | SPARK PLUG WRENCH 13/16 | 1.00 |