



Pos	Part Number	Description	Additional Text	Quantity
1	0025060256	HH collar screw M6x25 TX30		8.00
2	24130102000JA	Ignition cover TE		1.00
3	51740001033	electric starter assy.		1.00
4	51740002033	Bushing compl.		1.00
5	51740014000	Twin gear		1.00
6	55639007100	Ignition wire		1.00
7	51739193000	Spark plug		1.00
8	51739091000	Sealing boot		1.00
9	0025060256	HH collar screw M6x25 TX30		2.00
10	55639006000	Ignition coil		1.00
11	50439004010	PICKUP BRACKET		1.00
12	51739104000	Stator		1.00

13	51711059000	starter cable		1.00
14	0014050163	HH COLLAR SCREW M 5X16 WS=6		2.00
15	0912050303	AH SCREW DIN0912-M 5X30		3.00
16	51739105000	Flywheel		1.00
17	0770230010	O-ring, 23x1 NBR 70		1.00
18	51740012033	Console cpl.		1.00
20	50440026000	BENDIX		1.00
21	50430040000	GASKET IGNITION COVER		1.00
22	0402040980	Needle roll.DIN5402 NRB 4X9.8		2.00
23	55140030100	COLLAR BUSHING		1.00
24	55641031000	Control device EFI		1.00
25	55641030000	Holder control unit		4.00
26	0025060166	HH collar screw M6x16 TX30		2.00
27	0770250030	O-RING 25,00X3,00 NBR 70		1.00