



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|----------------------------|-----------------|----------|
| 1 | 76511059000 | STARTER-CABLE L=570MM 08 | | 1.00 |
| 2 | 75011059150 | BATTERY-CABLE L=170MM | | 1.00 |
| 3 | 76511097000 | GROUND CABLE L=420MM 08 | | 1.00 |
| 4 | 27011056044 | Retaining bracket | | 1.00 |
| 5 | 58411053100 | BATTERY 12V 8,6AH 03 | | 1.00 |
| 6 | 76511097000 | GROUND CABLE L=420MM 08 | | 1.00 |
| 7 | 58211058000 | Starter relay 12V 99 | | 1.00 |
| 8 | 58011109130 | Plug-in fuse, big 30A | | 2.00 |
| 8 | 58011109125 | FUSE 25 A | | 1.00 |
| 9 | 76511054100 | BATTERY BRACKET | | 1.00 |
| 10 | 61111057000 | RELAY CM1A-R-12V-H80 07 | | 4.00 |
| 11 | 0025050126 | HH collar screw M5x12 TX30 | | 3.00 |
| 12 | 76511055000 | HOLDER F.ELECTRIC 08 | | 1.00 |

| | | | | |
|----|-------------|--------------------------------|--------------|------|
| 13 | 43205062100 | silentbloc 20x15-M6x10-(1) | ONLY FOR USA | 3.00 |
| 14 | 0024060106 | HH COLLAR SCREW M6X10 TX30 | | 3.00 |
| 15 | 0902060083 | Oval head screw ISO 7380 M 6X8 | | 2.00 |
| 16 | 0912050083 | SHCS DIN 912 M5x8 | | 1.00 |
| 18 | 58211058050 | BRACKET RUBBER F.STARTRELAY 07 | | 1.00 |
| 19 | 27011056050 | absorber f. battery retaining | | 1.00 |
| 21 | 62111059060 | COVER POSITIVE POLE | | 1.00 |
| 22 | 12011016000 | WASHER 6 X 12 X 3 | | 2.00 |
| 23 | 0025060126 | HH collar screw M6x12 TX30 | | 3.00 |
| 24 | 0025060166 | HH collar screw M6x16 TX30 | | 2.00 |
| 25 | 0934060003 | Hex. nut DIN 934 M6 | | 2.00 |
| 26 | 0024060136 | HH collar screw M6x13 TX30 | | 2.00 |
| 28 | 58411098100 | CONTACT WASHER M6 VSV-K6 | | 3.00 |
| 29 | 0025060206 | HH collar screw M6x20 TX30 | | 1.00 |
| 30 | 60342090100 | inertial sensor | | 1.00 |
| 31 | 62142041000 | DAMP. COMPONENT ABS MODUL | | 3.00 |
| 32 | 61342041000 | Collar bushing 6.5X9X18X8.5 | | 3.00 |
| 33 | 76903001061 | Retaining bracket, angle senso | | 1.00 |
| 34 | 0025060256 | HH collar screw M6x25 TX30 | | 2.00 |