



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|--------------------------------|-----------------|----------|
| 1 | 28104030044C1 | Swing Arm Sub Assy Husqvarna 4 | | 1.00 |
| 2 | 90104032000 | sleeve bushing 15.1x20x38 | | 2.00 |
| 3 | 90104031000 | Igus plain bearing | | 4.00 |
| 4 | 90104036000 | Thrust washer 22.2x31.7x1 | | 2.00 |
| 6 | 90104034001 | OIL SEAL RING 25X32X7 | | 4.00 |
| 7 | 90104034000 | cup for radial shaft seal | | 4.00 |
| 8 | 90104046000 | swingarm adjusting ring | | 2.00 |
| 9 | 90104042000 | hex thrust washer | | 2.00 |
| 10 | 93013047000 | Support | | 1.00 |
| 11 | 90113047000 | brake hose guide | | 1.00 |
| 12 | J011050133 | HH COLLAR SCREW M5X13 SW8 | | 2.00 |
| 13 | 90104010002 | flanged hex nut M10x1.25 WS13 | | 2.00 |
| 14 | 90104040000 | BOLT HEX M10X1.25X50 WS10 | | 2.00 |
| 18 | 28104061000 | Chainguard fairing | | 1.00 |
| 19 | 28104062000 | Chainguard | | 1.00 |
| 20 | J981420133 | SHEET MET.SCR. DIN 7981 4,2X13 | | 4.00 |
| 21 | 93004065000 | hexagon socket screw M5X0.8X55 | | 1.00 |
| 22 | J912060162 | Hexagon socket screw, M6X16 | | 2.00 |

| | | | | |
|----|-------------|----------------------------|--|------|
| 24 | 90104038000 | FLANGED NUT M14X1.5 | | 1.00 |
| 25 | 90104037000 | Shaft swing arm L=299mm | | 1.00 |
| 26 | 90204060001 | HH COLLAR NUT | | 1.00 |
| 27 | 90104040100 | screw M5x0.8x30 | | 1.00 |
| 28 | 90504067000 | WASHER CHAIN SLIDING GUARD | | 1.00 |
| 29 | J025060169 | HH COLLAR SCREW M6X16 SW8 | | 2.00 |
| 30 | 90604062000 | chain slider bushing | | 2.00 |
| 31 | 90904070020 | SLEEVE CHAIN GUARD | | 1.00 |
| 99 | 90104066210 | CHAIN GUARD KIT 250/390 | | 0.00 |