



| Pos | Part Number    | Description                  | Additional Text | Quantity |
|-----|----------------|------------------------------|-----------------|----------|
| 1   | 28109001044C1A | Front wheel cpl.             | 36xxx           | 1.00     |
| 2   | J760223508     | SHAFT SEAL RING 22X35X8      |                 | 2.00     |
| 3   | J625062023     | BALL BEARING 6202            |                 | 2.00     |
| 4   | 90109011001    | Fixation bearing spacer tube |                 | 1.00     |
| 5   | 90109011000    | Spacer front wheel           |                 | 1.00     |
| 7   | J472035156     | Lock ring, 35x1.5            |                 | 1.00     |
| 9   | 28109072000    | Spoke nipple front M5x0.8    |                 | 36.00    |
| 11  | 28109071169    | Front spoke M5/4.37/169      |                 | 36.00    |
| 12  | 28509060000    | front brake disk D=320mm     |                 | 1.00     |
| 13  | J025080206     | Hex collar screw, M8x20      |                 | 6.00     |
| 14  | 28142020000    | Sensor wheel ABS front       |                 | 1.00     |
| 15  | J07046040086   | Countersunk screw, M4X08     |                 | 3.00     |
| 16  | 93009081000    | Front axle                   |                 | 1.00     |
| 17  | 28109083000    | Spacer, front wheel          |                 | 2.00     |
| 18  | 90109082000    | flanged bolt M8              |                 | 1.00     |
| 19  | 28109073000    | Tube protector front         |                 | 1.00     |
| 99  | 28509015010    | Front wheel repair kit       |                 | 0.00     |