



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|--------------------------------|-----------------|----------|
| 1 | 55530702044JA | Ignition cover TE compl. | | 1.00 |
| 2 | 55430040000 | IGNITION COVER GASKET | | 1.00 |
| 3 | 55439104000 | Stator | | 1.00 |
| 4 | 55439105000 | flywhell | | 1.00 |
| 5 | 0012050303S | Cap head screw DIN 6912 - M5x3 | | 3.00 |
| 6 | 55440126000 | BENDIX | | 1.00 |
| 7 | 55540001000 | Starter motor | | 1.00 |
| 8 | 0025060256 | HH collar screw M6x25 TX30 | | 9.00 |
| 9 | 55540031000 | Collar bushing | | 1.00 |
| 10 | 55440012000 | BEARING BUSH | | 1.00 |
| 11 | 0025060306 | HH collar screw M6x30 TX30 | | 3.00 |
| 12 | 55440040044 | PROTECTION CAP STARTER ENGINE | | 1.00 |
| 13 | 0770021260 | O-RING 34,59X2,62 | | 1.00 |

| | | | | |
|----|-------------|--------------------------------|-----|------|
| 14 | 55641030000 | Holder control unit | | 4.00 |
| 15 | 55439140220 | Holding plate generator cable | | 1.00 |
| 16 | 49030090100 | DOWEL 9,8 X7X10 | | 2.00 |
| 18 | 59039034000 | pulse generator KOKUSAN 4K3-A/ | | 1.00 |
| 19 | 0025050166 | HH collar screw M5x16 TX30 | | 2.00 |
| 22 | 55639007100 | Ignition wire | | 1.00 |
| 23 | 55439193000 | Spark plug | | 1.00 |
| 24 | 50231012000 | SEALING CUP FOR SPARK PLUG | 200 | 1.00 |
| 25 | 55639006000 | Ignition coil | | 1.00 |
| 26 | 0025060256 | HH collar screw M6x25 TX30 | | 2.00 |
| 27 | 55641031000 | Control device EFI | | 1.00 |