



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|-------------------------------|-----------------|----------|
| 1 | 28107013000 | Fuel tank | | 1.00 |
| 2 | 90507013006 | GROMMET TANK MOUNTING | | 2.00 |
| 3 | 93008034000 | Bushing | | 2.00 |
| 4 | 90507047041 | SEAT DUMPER SOZIUS SEAT | | 1.00 |
| 5 | 90507015000 | CONNECTOR Y SHAPE | | 1.00 |
| 6 | J025080253 | Hexagon screw M8X25 | | 3.00 |
| 7 | J600000635500 | Pipe connector | | 1.00 |
| 8 | 90111060010 | WASHER PLAIN 8,4X25X2 | | 1.00 |
| 9 | 93007014000 | Tank guard rear | | 1.00 |
| 10 | J031050096 | Roundhead screw, M5x9 | | 1.00 |
| 11 | J600000638500 | Pipe tank expansion-connector | | 1.00 |

| | | | |
|----|---------------|--------------------------------|------|
| 12 | J600000629000 | Overflow hose, D=6 L=290 | 1.00 |
| 13 | J310000801300 | Hose clamp 12.5 x 8 SW | 3.00 |
| 14 | 28107029010 | Rubber cap, ACF tank connectio | 1.00 |
| 15 | 28108057020 | Rubber bushing spoiler | 2.00 |
| 16 | 28108057000KC | tank top cover | 1.00 |
| 17 | J900000604501 | Hexagon socket screw M6x45 | 2.00 |
| 18 | 28108057010 | Bushing ignition lock cover | 4.00 |
| 19 | J900000501600 | SCREW TRUSS M5x16 | 6.00 |
| 20 | 28107040000 | Seat | 1.00 |
| 21 | 28107047000 | Pillion seat | 1.00 |
| 22 | 93007047041 | Seat damper | 2.00 |
| 23 | 93007040010 | Seat cowl pad | 4.00 |
| 24 | 28111066010 | Rubber grommet, ignition lock | 1.00 |
| 25 | J900000605001 | BOLT SOCKET-M6X1XL50XCL10.9XBL | 2.00 |
| 26 | 28107050000 | Seat lock | 1.00 |
| 27 | 90508006003 | AH SCREW M6X1X20 | 2.00 |
| 28 | J912080186 | Bolt socket-M8x1.25Xl18Xcl8.8X | 4.00 |
| 29 | 28112008000 | Passenger grab handle | 1.00 |
| 30 | 28107050010 | cable lock seat | 1.00 |
| 31 | 28112010033 | Baggage carrier compl. | 1.00 |
| 32 | 28107055000 | Passenger seat cover right | 1.00 |
| 33 | 28107055010 | Passenger seat cover left | 1.00 |
| 36 | 28112010010 | Collar bushing baggage carrier | 2.00 |