




Pos	Part Number	Description	Additional Text	Quantity
1	28109001044C1A	Front wheel cpl.	36xxx	1.00
2	J760223508	SHAFT SEAL RING 22X35X8		2.00
3	J625062023	BALL BEARING 6202		2.00
4	90109011001	Fixation bearing spacer tube		1.00
5	90109011000	Spacer front wheel		1.00
7	J472035156	Lock ring, 35x1.5		1.00
9	28109072000	Spoke nipple front M5x0.8		36.00
11	28109071169	Front spoke M5/4.37/169		36.00
12	28109060000	disc-brake-front 320 mm		1.00
13	J025080206	Hex collar screw, M8x20		6.00
14	28142020000	Sensor wheel ABS front		1.00
15	J07046040086	Countersunk screw, M4X08		3.00
16	93009081000	Front axle		1.00
17	28109083000	Spacer, front wheel		2.00

18	90109082000	flanged bolt M8		1.00
19	28109073000	Tube protector front		1.00
90	28109201044C1A	FR Wheel HUSQ SVART Spoke_Axle	Excel rim	1.00
99	28509015010	Front wheel repair kit		0.00