



| Pos | Part Number   | Description                    | Additional Text | Quantity |
|-----|---------------|--------------------------------|-----------------|----------|
| 1   | 96230000044C1 | Crankcase CPL                  |                 | 1.00     |
| 2   | J625062122    | BALL BEARING 15X35X11-C3-1     |                 | 2.00     |
| 3   | J410002001400 | bearing ball-id 20xod 47xthk 1 |                 | 1.00     |
| 4   | 90230079000   | STOPPER BALANCER SHAFT BEARING |                 | 2.00     |
| 5   | J01665060123S | Hex collar screw, M6x12        |                 | 2.00     |
| 6   | 90130004004   | Bearing ball                   |                 | 1.00     |
| 8   | J618131912    | NEEDLE ROLLER BEARING HK1312   |                 | 2.00     |
| 9   | 90234030000   | BUSH SHIFT RAIL                |                 | 2.00     |
| 10  | J760122455    | SHAFT SEALING RING 12X24X5,5   |                 | 1.00     |
| 11  | 0760122406    | Shaft seal ring 12x24x6        |                 | 1.00     |
| 12  | J625062041    | BALL BEARING 6204-Z/HN3        |                 | 1.00     |
| 13  | J710003012000 | Lock ring for hubs             |                 | 1.00     |
| 14  | J025060104    | Hex collar screw M6X10         |                 | 1.00     |

|    |               |                             |             |      |
|----|---------------|-----------------------------|-------------|------|
| 16 | 90140020002   | BRACKET F. FREE WHEEL GEAR  |             | 1.00 |
| 17 | J025060141    | Hex collar screw M6X14      |             | 1.00 |
| 18 | 90230022000   | Pipe breather               |             | 1.00 |
| 19 | J011050133    | HH COLLAR SCREW M5X13 SW8   |             | 2.00 |
| 20 | 90238029003   | OIL NOZZLE                  |             | 1.00 |
| 21 | 90130003004   | Seal - oil                  |             | 1.00 |
| 22 | J790001903000 | Seal Oil                    |             | 1.00 |
| 23 | 90230066300   | OIL NOZZLE                  |             | 1.00 |
| 27 | 96211023100   | sensor indicator gear       |             | 1.00 |
| 28 | J770002024000 | O RING                      |             | 1.00 |
| 29 | J025050163S   | FLANGED BOLT M5X16          |             | 2.00 |
| 30 | 96239034000   | Crankshaft position sensor  |             | 1.00 |
| 31 | J900000607001 | bolt flanged M6x1           |             | 9.00 |
| 32 | J025060350    | FLANGED BOLT M6X35 WS8      |             | 5.00 |
| 33 | 96204060000   | GUARD CHAIN                 |             | 1.00 |
| 34 | J005060123S   | SCREW PAN CROSS M6X12 PH SS |             | 3.00 |
| 35 | 96203096000   | COVER REAR LH               |             | 1.00 |
| 36 | J900000601607 | SCREW SOCKET M6X1           |             | 3.00 |
| 39 | 90130164000   | OIL NOZZLE                  |             | 2.00 |
| 42 | 90130003007   | DOWEL D14                   |             | 4.00 |
| 43 | 90130024000   | PIN DOWEL 8X6,4X14MM        | 14mm length | 1.00 |
| 44 | J011080203S   | FLANGED BOLT M8X20          |             | 1.00 |
| 45 | J603061001    | COPPER GASKET               |             | 1.00 |
| 47 | J900000608500 | bolt flanged M6x1           |             | 2.00 |