



Pos	Part Number	Description	Additional Text	Quantity
1	A67607013000C1	HUSQ801 FUEL TANK 44272047 BLC		1.00
2	76007080200	Fuel lever sensor		1.00
3	60307080090	Gasket fuel lever sensor		1.00
4	014579050166	Cap hd. screw ISO14579, M5x16-		8.00
5	58007117000	YDNAC-CLAMP 10107 10MM		1.00
6	A67607016000	Hose 6x10 FKM/ECO L=852		1.00
7	69011092000	Cable tie w. socket D=6.5		1.00
8	0610000600200	Angle piece 2 mm		1.00
9	A67607058000	Fuel tank fairing		1.00
10	0660003301000	Elastic buffer self-adhesive		6.00
11	54603048100	clip nut M6		2.00
12	54603048200	RANGE CHANGE METAL NUT M5		8.00
13	61908040030	Bracket for side fairing		2.00

14	62142041000	DAMP. COMPONENT ABS MODUL		2.00
15	61342041100	Collar bushing 6,5x9x18x8.5		2.00
16	0025060206	HH collar screw M6x20 TX30		2.00
17	A67607011033C1	Tank pad preass.		1.00
18	A67607040000C1B	Rider seat cmpl.		1.00
19	60006001021	Distance rupper airbox 03		6.00
20	A67607047000C1B	Passenger seat		1.00
21	0025050306	HH COLLAR SCREW M5X30 TX30		2.00
22	54603048600	RANGE CHANGE METAL NUT M5 INOX		2.00
23	21007049000	Rubber seat cowl pad		2.00