1

5

2



701 SUPERMOTO 270.01.198.000 SETTING look owner's manual	FORK			SHOCK		
	Compression (clicks)	Rebound (clicks)	Comp. low speed (clicks)	Comp. high speed (turns)	Rebound	Spring preload
Comfort	20	20	20	2,0	20	18mm
Standard	15	15	15	1,5	15	18mm
Sport	10	10	10	1	10	18mm
Max. payload	10	10	10	1	10	25mm

6

3



7

4



SPARE 25A	FUSE 25A	ABS control unit
SPARE 15A	FUSE 10A	ABS control unit
SPARE 15A	FUSE 9 - 10A	ABS wakeup, dashboard wakeup, bCCU wakeup, 6D sensor, OBD
SPARE 15A	FUSE 8 - 15A	ACC2, USB-charging, HCU
SPARE 10A	FUSE 7 - 10A	ACC1
SPARE 10A	FUSE 6 - 10A	High beam, low beam, positon-, tail-, licence light
SPARE 10A	FUSE 5 - 10A	Horn, brake light
SPARE 10A	FUSE 4 -10A	radiator fans
SPARE 10A	FUSE 3 - 10A	fuel pump
SPARE 10A	FUSE 2 - 10A	Ignition, ECU, EVAP, fuel injection, λ sensor
	FUSE 1 - 10A	Ignition, dashboard, bCCU
	SPARE 30A	
	FUSE - 30A	main fuse

A606.11.087.010

Pos	Part Number	Description	Additional Text	Quantity
1	A60007098100	Fuel tank sticker NA		1.00
2	27001198000	decal std setting 701FS		1.00
3	76504099000	Sticker "Kettenspannung"		1.00
4	A60611087010	Decal fuse box		1.00
5	LI26-A605-7B			1.00
6	LI26-A605-13B			1.00
7	LI25-A605-30B			1.00